

PLOT NO. 96 / A / SL - 6, SCHEME NO. 78 INDORE - 452010 (M.P.)

FAX: 0731-4002950 info@parashydrochem.com

# **EASY TEST KIT (For Water Hardness Checking)**

- 1. The Easy Test kit contains 3 Nos. hardness reagent chemical bottles, 100 mls each of HRP No. 1, No. 2, and No. 3.
- 2. The Easy Test kit is very much useful for instant checking water hardness by the Operators / Supervisors on the shop floor without using any lab equipments and without any complicated calculations and thus helps strict and regular control on treated water Quality.

### PROCEDURE FOR USING EASY TEST KIT FOR CHECKING WATER HARDNESS:

#### Α. **CHECKING SOFT WATER HARDNESS:**

- 1. Take 25 mls. Soft water in a beaker / Test tube.
- 2. Add 4 – 5 Drops of hardness reagent HRP No.1
- 3. Add 1-2 Drops of hardness reagent HRP No.2 until colour changes to RED.
- Now add hardness reagent HRP No.3 drop by drop, shake after each drop 4 until the colour changes from RED to BLUE.
- 5. Count the drops of reagent HRP No. 3 added.

### One Drop of HRP No. 3 = 1 ppm hardness as CaCo3

#### В. **CHECKING RAW WATER HARDNESS:**

- 1. Take 5 mls Raw Water sample.
- 2. Add 4-5 Drops of HRP No.1
- 3. Add 1-2 Drops of HRP No. 2 until colour changes to RED
- Add HRP No 3 drop by drop, until the colour changes from RED to blue 4

## One Drop of HRP No. 3 = 6.5 ppm Hardness as CaCo3

- **NOTE** : 1. It is important that reagent bottle's caps are not interchanged, precaution must be taken about this.
  - Store / keep in shed. 2.
  - Shelf life of HRP No. 2 is 3 months. 3.
  - 4. BLUE Colour, after HRP No. 2 addition, indicates ZERO Hardness in the water sample.